

**WALL AT SOFFIT
 WITH EXT. INSUL'N + GABLE ROOF - SECTION VIEW**

NOTE: Both starter strips + rain screen clips are to be hard fastened to wall. Horizontal siding installation begins with 1 starter strip at bottom of wall with siding continuing upward. Rain screen clips are recommended to be installed every 32" o/c. Diagonal furring strips fastened to wall studs are recommended to allow for ventilation and structural stability, as well as flexibility in allowing siding installation in any direction. Pieces of siding entering finishing strips are to be ripped along the top to allow for proper insertion into trim piece.

