

**WALL AT CORNER
 VERTICAL SIDING - PLAN VIEW**

NOTE: Both starter strips + rain screen clips are to be hard fastened to wall. Vertical siding installation begins with 2 starter strips back to back at centre of wall with siding continuing outward in both directions. Rain screen clips are recommended to be installed every 32" o/c. Pieces of siding entering finishing strips are to be ripped along the top to allow for proper insertion into trim piece.

