

**WALL AT SOFFIT
FLAT ROOF - SECTION VIEW**

NOTE: Both starter strips + rain screen clips are to be hard fastened to wall. Horizontal siding installation begins with 1 starter strip at bottom of wall with siding continuing upward. Rain screen clips are recommended to be installed every 32" o/c. Pieces of siding entering finishing strips are to be ripped along the top to allow for proper insertion into trim piece.

